

Materials:

Raw Beginning Wood Sizes:

Material	Thickness	Width	Length
MDF	3/4" (19.050 mm)	43 1/8" (1094.1 mm)	40" (1016 mm)
Plywood: Builder's Choice (Choose one)			
Plywood	1/4" (6.350 mm)	40" (1016 mm)	40" (1016 mm)
Plywood	3/8" (9.525 mm)	40" (1016 mm)	40" (1016 mm)

- T Track:
 - <https://www.rockler.com/universal-t-track-universal-t-track> \$29.99
 - https://www.eagleamerica.com/product/v416-0484/miter_track_t-track \$19.99
 - <https://www.amazon.com/Incra-TTRACKREG48-48-Inch-T-Track-Regular/dp/B000I6LW1W> \$29.90
 - https://www.amazon.com/dp/B06XSX88M9/ref=psdc_552488_t4_B000I6LW1W \$19.99
- Hardware for 1/4" Plywood:
 - Threaded Insert
 - Builder's Choice:

Insert Thread	Insert Size
• 10-24	• 10-24 x 1/4"
• M4-0.7	• M4-0.7 x 6.350
• M5-0.8	• M5-0.8 x 6.350
 - Screws – MDF:
 - Builder's Choice:

Screw Thread	Screw Size
• 10-24	• 10-24 x 5/8"
• M4-0.7	• M4-0.7 x 15.875 mm
• M5-0.8	• M5-0.8 x 15.875 mm
 - Screws – T Track:
 - Builder's Choice:
 - Builder to determine screw size depending on the screw size needed for the selected T-Track.
- Hardware for 3/8" Plywood:
 - Threaded Insert
 - Builder's Choice:

Insert Thread	Insert Size
• 10-24	• 10-24 x 3/8"
• M4-0.7	• M4-0.7 x 9.525
• M5-0.8	• M5-0.8 x 9.525
 - Screws – MDF:
 - Builder's Choice:

Screw Thread	Screw Size
• 10-24	• 10-24 x 5/8"
• M4-0.7	• M4-0.7 x 19.050 mm
• M5-0.8	• M5-0.8 x 19.050 mm
 - Screws – T Track:
 - Builder's Choice:
 - Builder to determine screw size depending on the screw size needed for the selected T-Track.
- Counter sink bit for builder's choice of screws

- Drill bit for builder's choice of screws
- feedback so I can improve on the next one.